



## Sleepy Monkey Floor Bed Assembly Manual

Congratulations on purchasing your very own Sleepy Monkey wooden floor bed! We're here to help you assemble it with ease. Follow these simple steps and your child's cozy sleeping space will be ready in no time.

---

### Tools You'll Need:

- Drill with Phillips head drill bit
- Clamp or zip ties (this is not essential but recommended to ensure there isn't a gap between the sides after drilling the screws)

---

### Important Tips:

1. **Assembly Location:** Assemble the bed as close as possible to its final position in the room. This will save you from moving a fully assembled bed, which can be cumbersome.
2. **Teamwork:** While this assembly can be done solo, having an extra pair of hands can make the process quicker and easier.
3. **Clamping the sides:** We recommend the sides be clamped together before drilling the screws as this will prevent a small gap between the sides. Clamps are easily found at Bunnings but you can also use zip ties to keep the sides tight while drilling.

---

### Step-by-Step Instructions:

#### Step 1: Prepare Your Workspace


1. Clear the area where you want to assemble the bed.
2. Lay a soft blanket or sheet on the floor to prevent scratching the wood.

#### Step 2: Identify and Organise the Bed Parts

1. Lay all four sides of the bed frame on the floor. Identify each piece:
  - a. Headboard and Footboard: The shorter pieces.
  - b. Side Rails: Two long pieces that will connect the headboard and footboard.

#### Step 3: Attach the Side Rails to the Headboard

1. Position the headboard upright in its final position.
2. Take one side rail and align it with the headboard leaving the side rail with the pre-drilled holes on the outside.
3. Insert the provided screws and use the drill to secure the rail to the headboard. Do not fully tighten the screws yet. Repeat this process for the other side rail.



Step 3.3. Screws

**Step 4: Attach the Side Rails to the Footboard**



1. Align the footboard with the bottom of the side rails so the pre-drilled holes are on the outside.
2. Insert the screws and use the drill to secure the side rails to the footboard. Again, do not fully tighten the screws yet.

**Step 5: Secure All Connections**

1. Once all four sides are connected and you are satisfied with the alignment, go back and fully tighten all screws. Ensure everything is snug and secure.

**Step 6: Place the Slats**

1. Ensure the bed is now in its final position in the room as the slats won't be attached to the frame.
2. Lay the long slats evenly across the bed frame - in line with the side rails - resting them on the floor. The purpose of these slats is to hold the next set of slats.
3. Lay the short slats on top of the long ones in line with the headboard and footboard. The purpose of these slats is to lift the mattress slightly off the floor for ventilation purposes.

**Step 6.2. Long/Vertical Slats****Step 6.3. Short/Horizontal Slats****Step 7: Final Adjustments**

1. Double-check all screws and connections to ensure everything is tight and secure.
2. The frame won't feel completely set yet as it will need the mattress to provide that extra sturdiness.

**Step 8: Add the Mattress**

1. Place your mattress on the slats and make the bed with your favourite bedding.

**Enjoy Your New Sleepy Monkey Floor Bed!**

If you have any questions or need further assistance, our friendly Sleepy Monkey team is here to help. Sweet dreams!

Thank you for choosing Sleepy Monkey! 🐒✨

**SLEEPY MONKEY**

Find more information in  
our help centre:

